



# UNITEC<sup>®</sup>

**A Pocket Guide  
to Unitec's  
PC Board Program**

**2007 rev. 2**

## **UNITEC's PC Board Program**

### **Three Options:**

#### **Exchange**

Reducing downtime is the most critical component of quality elevator service. Exchanging your PC board is the most efficient method for getting your elevator back in service quickly. UNITEC offers overnight delivery.

#### **Repair**

Repair is your most cost effective option. UNITEC's PC board repair process includes troubleshooting, replacement of defective components, and testing. Our state of the art in-circuit, functional, and simulator testing capabilities guarantee that your board is fixed right the first time. All boards are warranted for 45 days against defects.

#### **Purchase**

All PC boards listed may also be available for purchase. Call your UNITEC representative at 800.328.7840 for more information.

## *Table of Contents*

Armor PC Boards.....	3
BAXCO PC Boards.....	5
CEC PC Boards.....	7
Delta PC Boards.....	11
Dover PC Boards.....	13
Haughton PC Boards.....	31
Kone.....	43
Motion Control Engineering (MCE) PC Boards.....	45
Millar PC Boards.....	49
Montgomery PC Boards.....	51

*Table of Contents (continued)*

Otis PC Boards .....	65
Reliance.....	145
Schindler PC Boards .....	147
Thames Valley PC Boards.....	149
Thyssen-Krupp PC Boards.....	151
U.S. Elevator PC Boards.....	153
Westinghouse PC Boards .....	157
World Elevator PC Boards .....	185

### ***Armor PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
ARMRC058826101	C058826101	Timer, 1.0–5.0 Sec., 250 VDC
ARMRC058826104	C058826104	Timer, 0.5–5 Sec., 110 VDC
*ARMRC058-8261-0418	C058-8261-0418	Timer
ARMRC058-826105	C058-826105	Timer, 0.5–5.0 Sec.
ARMRC058-8261-05	C058-8261-05	Timer, 0.5–5.0 Sec.
*ARMRC058826203	C058826203	Timer, 5.0–40.0 Sec.
*ARMRC05882630-109	C05882630-109	Timer, 5–5 Sec., 110 V
ARMRC05882630-115	C05882630-115	Timer, 2–10 Sec., 110 V
*ARMRC05882630-208	C05882630-208	Timer

\* Currently repair only.

**ARMOR**

*Armor PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*ARMRD058800702	D058800702	Thyristor
*ARMRD0588371-01	D0588371-01	Car Control

\* Currently repair only.

***BAXCO PC Boards***

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*BXC01022	1022	BHMC-10 CONT PCB

\* Currently repair only.

**BAXCO**



***CEC PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
CEC01048	1048	Video Board
CEC01107	1107	GVI-1 Board for Modmaster/Swift 5000
CEC01150	1150	PMI-16 I/O-Unpopulated
CEC01172	1172	TOC Interface Board for Modmaster/ Swift 5000
*CEC01173	1173	Diode Board
CEC01225	1225	Car 8825 W/SBC341
CEC01226	1226	Group 8825 Board
CEC01290	1290	SBC-341 Board

\* Currently repair only.

***CEC PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
CEC01418	1418	Group 8825 w/SBC341
CEC01465	1465	Group 8825 w/SBC341, SBX351
CEC01466	1466	Car 8825 w/SBC341, SBX351
CEC01492	1492	RTG-3 Board for Modmaster/Swift 5000
CEC01498	1498	DAR-3 Board for Modmaster/Swift 5000
CEC01510	1510	REG-3 Board for Modmaster/Swift 5000
CEC01825	1825	Car 8825 Board

***CEC PC Boards******Unitec Part No.******OEM Part No.******Description***

CEC01826

1826

Serial Comm Mod RS422 for CPU

CEC01827

1827

SBC-18603A-03, Car/Group CPU  
Swift

CEC02090

2090

DAR-3 Board for Modmaster/Swift  
5000 w/DSD412

CEC02142

2142

CPT Board for Futura w/SCR Drive



### *Delta PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
DELT01-1274	01-1274	Driver Board
DELT50-1274	50-1274	Driver Board
DELT5049-00-0600	5049-00-0600	Analyzer Assembly



***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
D0VR105248	105248	Power Board
D0VR105251	105251	Board Top/Bottom 4KY Board
D0VR105252	105252	Interm Board Board
D0VR105254	105254	Option Board, 4-Slot Board
D0VR112261	112261	Opt Leveling Board
D0VR113065	113065	Dbl/Sgl Phase Rectifier
D0VR114129	114129	Rectifier Board
D0VR115298	115298	Rectifier, 3-Phase, 6-Amp
D0VR118412	118412	Emerg. Light Board

**DOVER**

*Dover PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
D0VR123948	123948	Car Board
D0VR124519	124519	Door, 4-Slot Board
D0VR126125	126125	Optical Leveling Board
D0VR140490	140490	MSC-I Regulator for Power
D0VR141305	141305	Power Unit Relay Board
D0VR141310	141310	CLC Main Processor Board
D0VR141317	141317	Selector Board
D0VR141323	141323	DMC Sensor Board
D0VR141329	141329	Micro Door Operator
D0VR141335	141335	Aux. Sensor Board

***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
D0VR141336	141336	CLC Board
D0VR141457	141457	MDC Aux. I/O Expansion Board
D0VR145557	145557	Opt Leveling Board
D0VR149355	149355	Emerg. Light
D0VR6300AA1	6300AA1	Main Sensor Board T-III
D0VR6300AA3	6300AA3	Main Sensor Board
D0VR6300AD2	6300AD2	REG Board for Dover T-III
D0VR6300AD4	6300AD4	T-III RTG Board
*D0VR6300AD5	6300AD5	Reg Board for Dover T-III

**DOVER**

*Dover PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
D0VR6300AE2	6300AE3	Selector I/O Board T-III
*D0VR6300BC1	6300BC1	SBC Board, 8086 T-III
D0VR6300BJ11	6300BJ11	DMC Power Relay Board
D0VR6300BJ13	6300BJ13	DMC-IA Power Board
D0VR6300BJ7	6300BJ7	DMC Power Relay Board
D0VR6300BJ8	6300BJ8	Power Relay Board for DMC-I
D0VR6300BP1	6300BP1	DMC CLC Board, Old
D0VR6300BP2	6300BP2	DMC CLC Board
D0VR6300BP3	6300BP3	DMC CLC Board
D0VR6300BP4	6300BP4	DMC CLC Board, New

\* Currently repair only.

### ***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
D0VR6300CD2	6300CD2	Main Sensor Board
D0VR6300CE2	6300CE2	Auxiliary Sensor for DMC-I
D0VR6300CN1	6300CN1	PMI T-III Board
D0VR6300CN2	6300CN2	PMI T-III Board
D0VR6300CN3	6300CN3	PMI T-III Board
D0VR6300CN4	6300CN4	PMI 48 I/O Board for Dover T-III / T-IV
D0VR6300CN5	6300CN5	PMI 48 I/O Board for Dover T-III / T-IV
D0VR6300CT4	6300CT4	CPU T-II Board

**DOVER**

*Dover PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
D0VR6300CT7	6300CT7	CPU, T-III/T-IV Board
D0VR6300CT8	6300CT8	CPU Group for Dover T-III
D0VR6300CT9	6300CT9	CPU Board Duplex T-IV
D0VR6300CV1	6300CV1	DMC Selector Board
D0VR6300CV2	6300CV2	DMC Selector Board
D0VR6300DC4	6300DC4	MDC Aux I/O Expansion Board
D0VR6300DC5	6300DC5	MDC Aux I/O Expansion Board
D0VR6300DG3	6300DG3	HDW/VAC. CON T-IV
D0VR6300EH1	6300EH1	Dover DMC-I HD85 Door Operator
D0VR6300ER4	6300ER4	CPU, T-III/T-IV

### *Dover PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
D0VR6300ER5	6300ER5	CPU, T-III/T-IV
D0VR6300FF1	6300FF1	Selector Leveling Board
D0VR6300FF2	6300FF2	Selector Leveling Board
D0VR6300FX1	6300FX1	HD85 Door Operator Board
D0VR6300FX2	6300FX2	Door Board, DMC-I
D0VR6300FX3	6300FX3	HD85 Door Operator Board
D0VR6300FX4	6300FX4	Door Card, Electronic
D0VR6300FX5	6300FX5	Dover DMC-I HD85 Door Operator
D0VR6300FX6	6300FX6	Door Operator Board

**DOVER**

*Dover PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
D0VR6300JC3	6300JC3	CPU Card 16 mHz
D0VR6300PY1	6300PY1	Dover Door Board
D0VR6300PY2	6300PY2	Dover DMC-I HD85 Door Operator
D0VR66691	66691	4-Slot Top and Bottom Board
D0VR67967	67967	Board Rectifier 3-Amp PWA 110
D0VR68177	68177	Power Board
D0VR68179	68179	Car, 3-Slot Board
D0VR68431	68431	Top/Bottom 3-Slot Board
D0VR68432	68432	Interim 3 Key Board
D0VR68525	68525	Board Option 3 Key PWA 136

***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
D0VR9714881	9714881	RTG Board for Dover T-III
D0VR9715710	9715710	CLC Processor for DMC-I
D0VR9716830	9716830	HD w/Vector Control Board for Dover T-IV
D0VR9730394	9730394	Power Supply 24 V Board
D0VR9740259	9740259	Tach Load Board for MSC1
D0VR9741331	9741331	Auxiliary Sensor for DMC-I
D0VR9753217	9753217	Option Board
D0VR9760027	9760027	DAR Board for Dover T-III
D0VR9760052	9760052	REG Board for Dover T-III

**DOVER**

*Dover PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
D0VR9766170	9766170	Rectifier Board
*D0VR9780014	9780014	Video Board
*D0VR9780026	9780026	DAR MMII Board
D0VR9780038	9780038	Parallel I/O Board
*D0VR9780040	9780040	REG Generator Field Regulator 4 Quad Board
*D0VR9780051	9780051	RTG-3 Board
D0VR9780063	9780063	SBC-88, Car Board
D0VR9780075	9780075	SBX-351, Slave Board
*D0VR9780087	9780087	Card Top-of-Car Digitizer w/o

\* Currently repair only.

### ***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*D0VR9780210	9780210	Car 8825 w/SBC341
*D0VR9780221	9780221	SBX-351, Master Board
D0VR9804134	9804134	HD85 Door Operator Processor
D0VR9805254	9805254	4-Slot Option Board, Oilhydraulic
D0VR9811266	9811266	Leveling Control Board
D0VR9813378	9813378	Decoder Board for MSC1
*D0VR9813937	9813937	LSS Card for Dover T-II
D0VR9813949	9813949	LSP Card for Dover T-II
D0VR9816094	9816094	Car/Group Mother Board
*D0VR9829015	9829015	8k RAM Memory Board

\* Currently repair only.

**DOVER**

***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*D0VR9829805	9829805	Reg Board for Dover T-III
D0VR9830390	9830390	Dover Power Supply
*D0VR9832373	9832373	CCS Board
D0VR9832439	9832439	Dover DMC-I HD85 Door Operator
D0VR9833080	9833080	Brt Timer
D0VR9834140	9834140	Optical Leveling Card
D0VR9836494	9836494	Dover DMC-I Power Relay Board
D0VR9839720	9839720	Dover Emergency Light Board
D0VR9840114	9840114	CPU Car (Intel) for Dover T-III/T-IV

\* Currently repair only.

***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
D0VR9840497	9840497	MSC-I Regulator Board
D0VR9841246	9841246	3-Phase Rectifier Board
D0VR9841301	9841301	DMC Power Relay Board
D0VR9841313	9841313	Selector Processor Board for
D0VR9841325	9841325	Main Sensor for DMC-I Board
D0VR9841337	9841337	CLC Processor Board for DMC-I
D0VR9841453	9841453	I/O Expansion Board for DMC-I
D0VR9841465	9841465	I/O Expansion Board (Options) DMC-I
D0VR9841490	9841490	I/O Expansion Board for DMC-I

**DOVER**

***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
D0VR9841507	9841507	DMC Power Supply
D0VR9843978	9843978	T-IV Inverter Snubber Board
D0VR9843991	9843991	CPU Card 16 MHz
*D0VR9845148	9845148	Relay Board
D0VR9845550	9845550	Optical Leveling Board
D0VR9851379	9851379	Power Relay Board for DMC-I
D0VR9853686	9853686	Main Sensor for Dover T-III
*D0VR9853704	9853704	PMI 16 I/O Board for Dover T-III
D0VR9853728	9853728	Sel. I/O Assm. for Dover T-III
*D0VR9853730	9853730	RTG Board for Dover T-III

\* Currently repair only.

***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*D0VR9853741	9853741	Serial Com. Master T-III
*D0VR9853753	9853753	Serial Comm. Slave T-III
D0VR9853765	9853765	Video Card Monochrome 6300AV9
*D0VR9853777	9853777	Video Board
*D0VR9853789	9853789	Video Board
*D0VR9853790	9853790	Video Board
*D0VR9853820	9853820	CPU Simplex Board T-III (Intel)
D0VR9855221	9855221	Car Board Board
D0VR9855233	9855233	Door Board Board
D0VR9855245	9855245	Power Board, 4-Slot Oildraulic

\* Currently repair only.

**DOVER**

*Dover PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
D0VR9855257	9855257	Top and Bottom, 4-Slot Board
D0VR9855269	9855269	Interm Hydro
*D0VR9860253	9860253	CPU Duplex Board T-III
*D0VR9860265	9860265	CPU Group for Dover T-III
*D0VR9860277	9860277	CPU Duplex for Dover T-III
D0VR9860289	9860289	CPU Car for Dover T-III
*D0VR9860290	9860290	CPU Board Duplex T-IV
D0VR9863000	9863000	PMI 48 I/O Board for Dover T-III / T-IV
D0VR9881232	9881232	PMI 48 I/O, w/o Modules, T-III

\* Currently repair only.

### ***Dover PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*D0VR9881323	9881323	HD85 Door Board for DMC-I
*D0VR9881359	9881359	Card PMI I/O 48-Pos w/o Modules
*D0VR9881797	9881797	Car Hydro Board
*D0VR9882534	9882534	CPU Card 80C186 Car 16MH2
D0VR9885213	9885213	Selector Leveling Board

\* Currently repair only.

**DOVER**

*Dover PC Boards*

*Unitec Part No.*

*OEM Part No.*

*Description*

### ***Haughton PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*HGTN0-51831-3	0-51831-3	CVTD Assembly
HGTN0-51839-7	0-51839-7	IRCH - Reliance Drive Assembly
HGTN0-51845-2	0-51845-2	Haughton Goldflite PRSC-GDCB Assembly
HGTN0-51849-1	0-51849-1	GDCB Assembly
*HGTN0-51865-1	0-51865-1	Haughton Goldflite CLDB Gate Driver Board
HGTN0-51874	0-51874	SSCA Assembly
HGTN0-51874-2	0-51874-2	SSCA Assembly
*HGTN3-40005-01	3-40005-01	Memory D Board

\* Currently repair only.

**HAUGHTON**

## HAUGHTON

### *Haughton PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*HGTN3-40005-02	3-40005-02	Memory Board for 1092 MC SAM/ GAM
*HGTN3-40005-04	3-40005-04	Counter C Board
*HGTN3-40005-05	3-40005-05	Counter C Board
*HGTN3-40005-26	3-40005-26	Pulse Generator
HGTN3-40005-27	3-40005-27	Pulse Generator
HGTN3-40008-53	3-40008-53	Haughton Goldflite System Control Board
*HGTN3-40020-51	3-40020-51	Haughton Predictor
HGTN3-40143-02	3-40143-02	SCR Trigger Board

\* Currently repair only.

### *Haughton PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*HGTN3-40179-87	3-40179-87	ELC Leveling Control
*HGTN3-40221-64	3-40221-64	VEVC Amplifier
*HGTN3-40221-73	3-40221-73	Mother Board Mod 5
*HGTN3-40221-95	3-40221-95	Mod V Fail Detector
*HGTN3-40221-96	3-40221-96	Mod V Fail Detector
*HGTN3-40229-95	3-40229-95	Amplifier Board
*HGTN3-40229-96	3-40229-96	Failure Detector Board
HGTN3-40229-98	3-40229-98	Failure Detector Board
HGTN3-40233-09	3-40233-09	Amplifier for Truflite EVCR
*HGTN3-40233-13	3-40233-13	Pattern Board Truflite EVCR

\* Currently repair only.

**HAUGHTON**

***Haughton PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
HGTN3-40246-69	3-40246-69	Amplifier
*HGTN3-40250-06	3-40250-06	Car Position
*HGTN3-40250-21E	3-40250-21E	Car Control
*HGTN3-40250-26	3-40250-26	Position Hall Call Buffer
*HGTN3-40254-46	3-40254-46	Static Sequence Card
*HGTN3-40254-93	3-40254-93	Current Loop Driver
*HGTN3-40254-94	3-40254-94	GDCB Board
*HGTN3-40255-26	3-40255-26	Haughton CV-TD
*HGTN3-40255-27	3-40255-27	Static Overload and Voltage
*HGTN3-40255-30	3-40255-30	PRSC Board, Static Drive Cards

\* Currently repair only.

### *Haughton PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*HGTN3-40255-49	3-40255-49	Static Drive Reliance Heat Sink
HGTN3-40255-50	3-40255-50	S6R High Voltage Heat Sink
*HGTN3-40256-73	3-40256-73	Reverse Phase, 180 V Board, Goldflite, GAC III
HGTN3-40259-45	3-40259-45	Haughton Goldflite Counter Board
*HGTN3-40259-45A	3-40259-45A	Haughton Goldflite Counter Board
*HGTN3-40261-81	3-40261-81	Data Priority
*HGTN3-40261-85	3-40261-85	Input Priority
*HGTN3-40264-47	3-40264-47	Haughton Goldflite Relay Driver
HGTN3-40266-43	3-40266-43	Relay Driver 64 Floors

\* Currently repair only.

**HAUGHTON**

**HAUGHTON*****Haughton PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
HGTN3-40267-48	3-40267-48	S6R Pattern Gen
HGTN3-40267-48F	3-40267-48F	Pattern Generator
*HGTN3-40271-69	3-40271-69	Haughton Goldflite Input Priority Board
*HGTN3-40271-69B	3-40271-69B	Haughton Goldflite Input Priority Board
HGTN3-40277-03	3-40277-03	Haughton Goldflite Memory Board 64-Stop
*HGTN3-40277-03B	3-40277-03B	Haughton Goldflite Memory Board 64-Stop
*HGTN3-40277-03C	3-40277-03C	Haughton Goldflite Memory Board

\* Currently repair only.

### *Haghton PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*HGTN3-40277-78B	3-40277-78B	64-Stop GMG Amp Board
*HGTN3-40280-14	3-40280-14	Accessory Board
HGTN3-40280-18	3-40280-18	Haghton Goldflite Timer Board
*HGTN3-40280-18F	3-40280-18F	Haghton Goldflite Timer Board
*HGTN3-40280-33	3-40280-33	Dynatron CAC Heat Sink Assembly (LV)
HGTN3-40280-34	3-40280-34	GAC Sink Assembly
HGTN3-40280-81	3-40280-81	Haghton Goldflite Pattern Genera- tor Board

\* Currently repair only.

**HAUGHTON**

## HAUGHTON

### *Haughton PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
HGTN3-40280-81E	3-40280-81E	Haughton Goldflite Pattern Generator Board
HGTN3-40280-85	3-40280-85	Haughton Goldflite Predictor
*HGTN3-40280-85C	3-40280-85C	Haughton Goldflite Predictor
HGTN3-40280-89	3-40280-89	Sam Motor Field Control
*HGTN3-40280-97	3-40280-97	Haughton Goldflite Position I/O Board
*HGTN3-40281-06	3-40281-06	GMG Amp
HGTN3-40281-07	3-40281-07	GMG Amp
HGTN3-40281-60	3-40281-60	Geared S6R/GDC Amplifier

\* Currently repair only.

### *Haughton PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
HGTN3-40281-95	3-40281-95	Gearless S6R Amplifier Board
HGTN3-40283-10	3-40283-10	GAC Amplifier
HGTN3-40289-46	3-40289-46	SAM/ GAM I/O Buffer
HGTN3-40290-10	3-40290-10	Haughton Goldflite Amplifier Board
*HGTN3-40290-10C	3-40290-10C	Haughton Goldflite Amplifier Board
HGTN3-40290-10F	3-40290-10F	Haughton Goldflite Amplifier Board
HGTN3-40290-58	3-40290-58	SSCC Board - S6RFM Static Drive
HGTN3-40292-28	3-40292-28	Data Priority
HGTN3-40292-28B	3-40292-28B	Data Priority
*HGTN3-40292-28C	3-40292-28C	Data Priority

\* Currently repair only.

**HAUGHTON**

## HAUGHTON

### *Haughton PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*HGTN3-40292-32	3-40292-32	Haughton Goldflite SAM/GAM Board
*HGTN3-40292-32D	3-40292-32D	Haughton Goldflite SAM/GAM Board
*HGTN3-40318-71	3-40318-71	Static Drive Reliance Heat Sink
HGTN3-40318-72	3-40318-72	Haughton Heat Sink Assembly
*HGTN3-40332-84	3-40332-84	Heat Sink 250 Amps
*HGTN3-40332-85	3-40332-85	Heat Sink 350 Amps
*HGTNW-002	W-002	SBC-88-25

\* Currently repair only.

*Haughton PC Boards*

*Unitec Part No.*

*OEM Part No.*

*Description*

\* Currently repair only.

**HAUGHTON**



***Kone PC Boards***

***Unitec Part No.***

***OEM Part No.***

***Description***

KONE515572

515572

Relay Board



### ***Motion Control Engineering (MCE) PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MCECHC-CI/O REV3	HC-CI/O REV3	Call Board
MCECHC-CI/O REV4	HC-CI/O REV4	Call Board
*MCECHC-CI/O-1A	HC-CI/O-1A	Call Board
MCECHC-CI/O-1B	HC-CI/O-1B	Call Board
MCECHC-CI/O-E	HC-CI/O-E	Call Board
*MCECHC-CI/O-L	HC-CI/O-L	Call Board
MCECHC-CI/ON	HC-CI/ON	Call Board, Neon
MCECHC-DFLS	HC-DFLS	DF Land Board
MCECHC-DFLS-TR	HC-DFLS-TR	DF Land Board

\* Currently repair only.

***Motion Control Engineering (MCE) PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MCECHC-PCIO	HC-PCIO	Power and Call I/O Board
MCECHC-I/OX	HC-IOX	I/O Extender Board
MCECHC-I4O	HC-I4O	I/O Expander, 16 In / 4 Out
*MCECMC-PC-1	MC-PC-1	Program Control Board
MCECHC-PCIO-L	HC-PCIO-L	Power and Call Board
MCECHC-PI/O	HC-PI/O	Power I/O Board
MCECHC-PI/O-1B	HC-PI/O-1B	Power I/O Board
MCECHC-PI/O-1C	HC-PI/O-1C	Power I/O Board
MCECHC-PIX	HC-PIX	8-Bit PI Board

\* Currently repair only.

### ***Motion Control Engineering (MCE) PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MCECHC-PIX-16	HC-PIX-16	16-Bit PI Board
MCECMC-MP	MC-MP	Processor Board
*MCECMC-MP-1	MC-MP-1	Processor Board
MCECMC-MP-1ES	MC-MP-1ES	Processor Board
*MCECMC-PA	MC-PA	Communication Processor Board
MCECMC-PCA-0A	MC-PAC-0A	CPU Board
MCECHC-RPSDB	HC-RPSDB	Door Power Supply Board

\* Currently repair only.



### ***Millar PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*MILR3-40392-56	3-40392-56	CVT CPU Board
MILR3-40393-54	3-40393-54	I/O Board for CVT, AI System
*MILRPWB-1004	PWB-1004	Analog Isolation Amplifier Board
*MILR-SBC-519	SBC-519	Millar and Microscan I/O Board
*MILR-SBC-519-KIT	SBC-519-KIT	Multi-Bus Millar/Westinghouse Board
*MT-128001	MT-128001	Traffic Analyzer

\* Currently repair only.

**MILLAR**



### *Montgomery PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*MAC0P-15764	15764	MAC Speed Board
*MAC0P-15766	15766	Mother Board
*MAC0P-24170	24170	MAC Speed Board
*MAC0P-24172	24172	MAC Power Board
*MAC0P-24173	24173	HP Power Board
*MAC0P-24561	24561	MAC Speed Board
*MAC0P-24783	24783	BD 104 Door Control
MAC0P-24783-004	24783-004	BD 104 Door Control
*MTGM12M03-00078-00	12M03-00078-00	Motor Field Power Unit

\* Currently repair only.

**MONTGOMERY**

**Montgomery PC Boards**

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MTGM-46246	46246	Motor Field Control Board - 6010
*MTGM46255-001	46255-001	2CA SSC6010
*MTGM46256-001	46256-001	3CA SSC6010
*MTGM46257	46257	4CA SSC6010
*MTGM90153-006	90153-006	1395 Digital DC Drive 56 Amp
*MTGM90154-002	90154-002	Drive, 1395 DDC 80 Amp, 460 VAC Series
*MTGM91980-002	91980-002	1336 80 Amp AC Drive
*MTGMA-46223	A-46223	Power Board

\* Currently repair only.

### ***Montgomery PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*MTGMB-47109	B-47109	Universal Input II - Bare Board
*MTGMB-47130	B-47130	Universal AC Output - Bare Board
*MTGMB-49711	B-49711	Power Relay Board
MTGMP-15730	P-15730	Input, MIPROM Non-Serial
MTGMP-15731	P-15731	Universal Input II w/Molex Connector
*MTGMP-15758	P-15758	Timer Board
MTGMP-15759	P-15759	Timer Board X8
MTGMP-15760	P-15760	Timer Board X14
MTGMP-15761	P-15761	Input w/Terminal Block Connector

\* Currently repair only.

**MONTGOMERY**

**Montgomery PC Boards**

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MTGMP-15762	P-15762	Universal Input II w/Molex Connectors
MTGMP-15764	P-15764	MAC Speed Board
*MTGMP-15765	P-15765	Power Door
MTGMP-15766	P-15766	MAC Speed Control Board
MTGMP-15771	P-15771	Card Rack, MIPROM I/O Lm317t
MTGMP-15774	P-15774	Output 8x AC W/Dual Triax, Molex Connector
MTGMP-15775	P-15775	Output 8x w/Terminal Connector
MTGMP-15778	P-15778	DC Output, w/Terminal Connector

\* Currently repair only.

### ***Montgomery PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MTGMP-15783	P-15783	Common Board
*MTGMP-15785	P-15785	Input Board with Terminal Strip
MTGMP-15828	P-15828	Hydro PM Relay, Finl
MTGMP-15838	P-15838	Card Rack
MTGMP-15839	P-15839	CPU I/O Cardrack – Montgomery MIPROM
MTGMP-15903	P-15903	Power Supply
*MTGMP-16363	P-16363	Speed Control
*MTGMP-16364	P-16364	Relay Power Door Board
MTGMP-16553	P-16553	Timer

\* Currently repair only.

**MONTGOMERY**

**Montgomery PC Boards**

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*MTGMP-16757	P-16757	Hydro PM Board
*MTGMP-16775	P-16775	4 AC and 4 DC Output Board
*MTGMP-16776	P-16776	Universal AC Output, w/Terminal Connector
*MTGMP-16777	P-16777	AC Output w/Molex Connector
*MTGMP-16778	P-16778	DC Output w/Terminal Block Connector
*MTGMP-16779	P-16779	Timer 4x
*MTGMP-16780	P-16780	Timer 9x
*MTGMP-16785	P-16785	Universal Input Board, w/Terminal Block Connectors

\* Currently repair only.

### *Montgomery PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*MTGMP-16786	P-16786	Universal Input II, w/Molex Connector
MTGMP-16802	P-16802	I/O Card Rack - Montgomery MIPROM
MTGMP-16835	P-16835	MIPROM Power
MTGMP-24100	P-24100	Montgomery MIPROM 21 – Relay Output
MTGMP-24103	P-24103	SS Multiple Operator Amp
MTGMP-24105	P-24105	SS Field Regulation
MTGMP-24107	P-24107	Dual Bridge Field Control 240 V

\* Currently repair only.

**MONTGOMERY**

*Montgomery PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
MTGMP-24114	P-24114	SS RFF Board
MTGMP-24115	P-24115	SSC - 6010 Board
MTGMP-24117	P-24117	Universal Board
MTGMP-24119	P-24119	OCA Board
MTGMP-24120	P-24120	7CA SSC-6010 – Montgomery MIRPOM 21
MTGMP-24147	P-24147	Montgomery MIPROM 21 - Output
MTGMP-24151	P-24151	MIPROM 21 - Output w/Terminal
MTGMP-24170	P-24170	Speed Board
MTGMP-24172	P-24172	Power Board

### *Montgomery PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
MTGMP-24173	P-24173	Montgomery Door Operator
MTGMP-24288	P-24288	Mother Board MIPROM 21
MTGMP-24298	P-24298	Montgomery MIPROM 21 PROM
MTGMP-24301	P-24301	Montgomery MIPROM 21, P I/O
MTGMP-24302	P-24302	Montgomery MIPROM 21, P I/O Buffer
MTGMP-24321	P-24321	MSU, Montgomery
MTGMP-24323	P-24323	M2, Relay Pilot
MTGMP-24377	P-24377	Montgomery MIPROM 21 CPU
MTGMP-24440	P-24440	Montgomery MIPROM 21 RS-232

Interface

**MONTGOMERY**

**Montgomery PC Boards**

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MTGMP-24441-001	P-24441-001	Montgomery MIPROM 21 RS-485 Interface
MTGMP-24561	P-24561	MAC Motor Power Board
*MTGMP-24562	P-24562	MAC High Performance Door Speed
MTGMP-24568-001	P-24568-001	NTS Board
MTGMP-24568-002	P-24568-002	NTS Board
MTGMP-24568-003	P-24568-003	NTS Board
MTGMP-24568-005	P-24568-005	NTS Board
MTGMP-24571	P-24571	EST Board

\* Currently repair only.

### ***Montgomery PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*MTGMP-24615	P-24615	Miprom CPU Board
*MTGMP-24700-001	P-24700-001	MST2, 110 AC, Relay
*MTGMP-24700-002	P-24700-002	MST2 Relay Input
*MTGMP-24700-003	P-24700-003	MST2, 110 VDC, Relay
*MTGMP-24700-004	P-24700-004	MST2, 230 VDC, Relay
*MTGMP-24783	P-24783	Door Board
*MTGMP-24783-004	P-24783-004	Door Board
*MTGMP-24785	P-24785	M2 Memory Board
*MTGMP-24842	P-24842	Montgomery MIPROM 21 286 PROM

\* Currently repair only.

**MONTGOMERY**

**Montgomery PC Boards**

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MTGMP-24869-003	P-24869-003	PI, Digital, #3, w/EPROM, Service
*MTGMP-24872	P-24872	Montgomery MIPROM 21 CPU
MTGMP-24873	P-24873	Montgomery MIPROM 21 CPU
MTGMP-24972	P-24972	Montgomery MIPROM 21 MSU
*MTGMP-26250-232	P-26250-232	Dual Bridge Field Control, 480 V
MTGMP-29077	P-29077	Power Supply - Montgomery
*MTGMP-29089	P-29089	Power Supply
MTGMP-29629-001	P-29629-001	Universal Input II w/Terminal
MTGMP-29629-002	P-29629-002	Universal Input II w/Terminal
MTGMP-29630-001	P-29630-001	Universal. Input II w/Molex

\* Currently repair only.

### ***Montgomery PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
MTGMP-30323	P-30323	Card Rack Assm., MIPROM 21
MTGMP-30387	P-30387	Montgomery MSU
MTGMP-30390	P-30390	Montgomery MSU
MTGMP-31675	P-31675	Pilot Relay Board
MTGMP-31787-001	P-31787-001	ESC Board
MTGMP-31787-003	P-31787-003	ESC Board
MTGMP-31787-004	P-31787-004	ESC Board
MTGMP-31807-002	P-31807-002	MIPROM 21 CPU Board
MTGMP-32302-002	P-32302-002	Montgomery E-5000 CPU Board

\* Currently repair only.

**MONTGOMERY**

***Montgomery PC Boards******Unitec Part No.******OEM Part No.******Description***

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*100-8112B3	Car Variable 3 (CV3) PCB
100-A8112J1	PC Board
*100-A8114F1	Security Cutout PCB
100-A8116B1	Mech. Hall Call Reg PCB
100-B8112A1	PC Board
100-B8112C1	Delayed Car + Door Protection-R PCB
*103-A8124AL1	Special Emergency Service PCB
108-A8124AL1	Special Emergency Service PCB
10-A8125AL1	Group Emerg. Power for EDP or E3P (G01)

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

110-A8124AL1	Special Emergency Service PCB
*113-A8124AL1	Special Emergency Service PCB
*114-A8124AL1	Supplemental Interface PCB
*114-A8124AL10	Supp. Interface Function PCB
*114-A8124AL3	PC Board
*11-8125AL1	Repair and Return PC Board
*11-A8125AL1	PC-Board
*125-A8124AL1	PC Board, Lined Up for Repair
*131-A8124AL1	PC Board
*133-A8124AL1	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*134-A8124AL1	PC Board
135-A8124AL2	PC Board
139-A8124AL1	PC Board
*13-A8124AL1	PC Board, Repair Only
13-A8125AL3	R-PC Board
*141-A8124AL1	PC Board
*142-A8124AL1	PC Board
*14-8124AL1	PC Board, Motion-GWT
*15-A8124AL1	Repair and Return PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

*16-8124AL1	PC Board, Motion-GWT
*16-8124AL3	Repair and Return PC Board
*16-A8124AL1	Repair and Return PC Board
1-7088B1	Circuit Board
*17-8124AL1	PC Board, Motion-GWT
*18-A8124AL10	PC Board
*19-8124AL1	PC Board, Motion-GWT
*19-8124AL2	WTC/PCB
*19-A8124PB1	PC Board
1-A8119AK1	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

1-A8119AK2	PC Board
*1-A8119P1	Repair PCB
*1-A8123A7	PC Board
1-A8124A5	Floor Functions Lower Deck (Fif-F5f) PCB
*1-A8124AL1	PC Board
*1-A8124AL3	Repair and Return PC Board
1-A8124B1	Door Operation, Door Time - Upper Deck PCB
1-A8124C1	Rear Direction and Hall Lantern PCB
*1-A8124H1	Car Variable No. 2 (Cv2h)

\* Currently repair only.

**OTIS**

***Otis PC Boards******Unitec Part No.******Description***

*1-A8124PB1	Repair and Return PC Board
*1-A8124Y1	120 VDC Interface - Lower Deck PCB
1-A8125AL1	15-Volt Power Supply PCB
*205410-3	Power Supply Assm.
205410-4	Power Supply Assm.
*21-A8124AL1	P C Board
*22-A8124AL1	PC Board
*22-A8124AL2	PC Board
*23-A8124AL1	PC Board
*23-A8124SS1	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

\*24-A8124AL1

PC Board

24-A8124SS1

PC Board

\*25-A8124AL1

PC Board

\*25-A8124SS1

Repair and Return PC Board

\*26-A8124AL1

Repair and Return PC Board

\*26-A8124AL2

PC Board

\*26-A8124SS1

WTC/PCB

\*27-A8124AL1

PC Board

28-A8124SS1

PC Board

\* Currently repair only.

**OTIS**

***Otis PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>Description</i></b>
*29-A8124AL1	PC Board
29-A8124SS1	PC Board
*2-A8124A4	For Repair Usage Only
*2-A8124A5	PC Board
*2-A8124AL1	PCB Board
*2-A8124AL2	PC Board
*2-A8124PB1	PCB, Chicago Special Emergency Service Board
*2-A8125PB5	Repair and Return PC Board
*30-A8124AL1	PC Board
*31-A8124PB1	Repair and Return PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

\*34-A8124AL2

Pre-Amplifier Card

3-A8124AL1

Repair and Return PC Board

\*3-A8125AL2

Group Emerg. Power Car

43-A8124AL1

PC Board, Lined Up for Repair

46-A8124AL1

Repair and Return PC Board

\*46-A8124AL2

PC Board

\*48-A8124AL1

PC Board

\*51-A8124AL1

PC Board

\*51-A8124PB3

PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards*

<i>Unitec Part No.</i>	<i>Description</i>
*52-A8124AL3	PC Board
*53-A8124AL1	PC Board
*54-A8124PB1	PC Board
*55-A8124AL1	Car Shuttle Service No. 2
*56-A8124AL2	PC Board
*57-A8124PB1	Circuit Board
*5-A8124AL1	PCB, Direction One Floor Run & Residual Card
*621J1	Power Supply
621W1	PS-VF (New) Main-Pri

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

\*64-A8124AL1

PC Board

\*64-A8124AL2

PC Board

\*6840AY1

Panel Assembly

6840CH1

Panel

\*6-A8124SS1

B Base OCB

\*7048AD1

Power Supply

\*7048AW1

Preamplifier

\*7048G2

Power Supply

7088AB

Repair and Return PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

\*7088AT1

Circuit Board

7088B1

Repair and Return PC Board

7088B2

Repair and Return PC Board

7088G

Repair and Return PC Board

7088H

Repair and Return PC Board

7088J

Repair and Return PC Board

7088P

Repair and Return PC Board

7088R

Repair and Return PC Board

7088T

Repair and Return PC Board

7088W

Repair and Return PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

70-A8124AL1

Repair And Return PC Board

\*70-A8124AL2

PC Board

\*7125L1

CPU Module Assm.

7125L4

CPU Module Assm.

7125L5

I/O Assm. Display

7125L6

I/O Assm. 1 & 2 Car Grp.

\*7125L7

I/O Assm. 3 & 4 Car Grp.

7125L8

I/O Assm. 5 & 6 Car Grp.

7\*142BC1

LRV3 Test Fixture

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

*73-8124AL1	WTC/PCB
*7416E1	W57795-Drive
*7416E2	Base Drive Assembly/Transistor Phase A
*7416E3	Base Drive Sub-Assembly
*7416E4	Base Drive Assembly/Transistor Phase C
*7596B1	Repair and Return PC Board
*7900AX1	ERU/LRV3, 4, 5
*80-A8124AL1	PC Board
*8110A5	PC Board
*8114A1	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

8120A1	PCB Optical Sensor
8120B1	PC Board
*8120B2	PC Board
8120C1	PC Board
8120C2	Binary Reading Board
8120E1	PC Board
8120F1	PC Board
8120F2	PC Board
8120G1	Slowdown Control Printed Circuit Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

8120P1	Binary Decoder Interface PC Board
*8120R1	PC Board
8128CM1	Comparator Assm. PCB
8128CN1	Amplifier Assm. PC Board
8128EE1	PC Board, Cntrl Int
8128GE2	Stepper PCB-8 Relays
8128GE3	Electronic Stepper PC Board, Assembly
*8200A1	Readout Assm.
8200AJ1	BP-Operator Pane
8200AR1	PCB-Data Distribution

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

8200AR2	IDS-Distribution Board
8200AT1	IDS-Gen-Purpose Int
*8200BB2	PCB IDS with ICs Computer Board
*8200BB3	IDS Processor Board
*8200BE1	Gong Board
8200BJ1	PCB-Keybd. Intf-96s
*8200CA4	PC Board R/F
*8200EA2	PC Board Communication-HTS Buffer
*8200EB1	PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

\*8200EB5

OKI Speech PC Board

8211A1

PC Board

\*8211B1

PC Board

8403A1

Adfix Cab Fixture Interface PC Board

\*87-A8124AL1

Repair and Return PC Board

\*87-A8124AL2

Repair and Return PC Board

\*88-A8124AL1

Repair and Return PC Board

\*90-A8124AL1

PC Board

\*9673AF1

PC Board

\*9693AE1

Remote St Extender

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*9708AB1	PC Board
9708AG1	PCB
*9708AL1	Thyristor Panel
9708BH1	PCB Interface Board
*9708BJ1	Power Pack w/Fan
*9708BJ2	Thyristor Panel
*97-A8124AL1	PC Board
*98-A8124AL1	PC Board
9-A8124AL1	PC Board, Repair Only

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

\*9-A8124AL3

MOS PCB

\*A621G1

Carrier Power Supp

A621J1

Power Supply Multi Output DC

A628G1

Battery Charger

\*A7048AD1

Power Supply

A8110A1

PC Board

A8110A2

PC Board

A8110A3

PC Board

A8110A4

Circuit Board

A8110A5

Circuit Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

A8110B1	Circuit Board
*A8110C2	Repair and Return PC Board
*A8110G1	PC Board
A8111A1	Circuit Board
*A8111A2	PC Board
A8111A3	Circuit Board
*A8111B1	Circuit Board
A8111B2	PC Panel
A8111B3	Circuit Board

\* Currently repair only.

**OTIS**

*Otis PC Boards*

<i>Unitec Part No.</i>	<i>Description</i>
A8111B4	PC Board
A8111B5	PC Board
*A8111B7	PC Board
*A8111C2	PC Board
A8111C3	Circuit Board
A8111D2	Circuit Board
A8112A3	Delayed Car & Door Protection PC Board
*A8112B1	Circuit Board
*A8112B2	Circuit Board
A8112B3	Circuit Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A8112B4	PC Board
*A8112B7	Repair and Return PC Board
*A8112C1	PC Board
A8112C10	PC Board
*A8112C11	PC Board
A8112C12	PC Board
*A8112C13	PC Board
A8112C2	PC Board
A8112C3	PC Board

\* Currently repair only.

**OTIS**

***Otis PC Boards******Unitec Part No.******Description***

*A8112C8	PCB-CV2, Car Variable No. 2
A8112D1	PC Board
A8112D2	PC Board
A8112E1	PC Board
*A8112F1	PC Board
*A8112F2	PC Board
*A8112F3	PC Board
A8112G1	PC Board
A8112H1	PC Board
A8112H3	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A8113A3	PC Board
A8113B2	PC Board
*A8113B3	PC Board
A8113B4	PC Board
*A8113B5	PC Board
*A8113B6	PC Board
*A8113B7	Circuit Board
A8113C1	PC Board
A8113C2	PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards*

<i>Unitec Part No.</i>	<i>Description</i>
*A8113C3	Circuit Board
*A8113D1	PC Board
A8113D2	Circuit Board
A8113E1	PC Board
A8113F1	Circuit Board
*A8113G1	Circuit Board
*A8113G2	PC Board
A8113H1	PC Panel
*A8113H2	PC Board
*A8113H3	Circuit Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A8113J1	PC Board (CV4)
*A8113J3	PC Board
*A8113K1	PC Board
*A8113K2	Repair PC Board
*A8113K3	PC Board
*A8113N10	PC Board
*A8113N11	PC Board
*A8113N2	PC Board
*A8113N5	PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

*A8113N8	Repair and Return PC Board
A8113P2	PC Board
*A8113P3	Circuit Board
*A8113P6	PC Board
*A8113P7	PC Board
A8113R1	PC Board
A8114A1	Circuit Board
A8114AA1	PC Board
A8114AA10	PC Board
A8114AA11	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

A8114AA3

PC Board

\*A8114AA5

PC Board

A8114AA7

Supplementary Interface Function PC

A8114AB1

PC Board

A8114AB2

PC Board

A8114AD1

PC Board

A8114AD4

PC Board

\*A8114B1

PC Board

\*A8114B2

PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards*

<i>Unitec Part No.</i>	<i>Description</i>
*A8114B3	PC Board
A8114B4	PC Board
A8114B5	Circuit Board
*A8114C1	PC Board
*A8114C2	PC Board
*A8114C3	PC Board
*A8114C4	PC Board
A8114C5	Circuit Board
*A8114D1	PC Board
A8114D2	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

A8114D3

PC Board

\*A8114D4

PC Board

A8114D5

Circuit Board

A8114E1

PC Board

A8114E2

PC Board

A8114E3

PC Board

A8114E4

PC Board

A8114E5

Circuit Board

A8114F1

Circuit Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

A8114G1	Circuit Board
*A8114K1	PC Board
*A8114K3	PC Board
*A8114K4	PC Board
A8114K5	PC Board
A8115A1	PC Board
A8115B1	PC Board
*A8115B2	PC Board
A8116A1	PCB Electronic Hall Call Register
*A8116A10	Circuit Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

A8116A11	Circuit Board
A8116A12	Circuit Board
*A8116A3	PCB Electronic Hall Call Register
*A8116A4	PC Board
*A8116A6	PC Board
*A8116A7	PC Board
*A8116A9	Circuit Board
A8116B1	PCB Board
A8116B2	PCB Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

A8116B3

PCB Board

A8116B4

PCB Mechanical Hall Call Register

A8117A1

PC Board

A8117A2

PC Board

\*A8117A3

PC Panel

A8117A4

PC Panel

\*A8118A1

Circuit Board

A8119AL2

Relay Board

A8119AM1

Component Board

\*A8119AM2

Component Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A8119AN1	PC Board
A8119AN2	Component Board
*A8119AN3	Component Board
*A8119AP2	PC Board
*A8119AT1	PC Board, BM
*A8119AT2	PC Board, BP
A8119AT4	PC Board
A8121AA1	Timer Board C-3036
A8121AA10	Timer Board-MPO

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

A8121AA11	MRVF PC Board
*A8121AA2	Timer Board C-3036
A8121AA3	Timer Board
*A8121AA4	Timer Board C-3036
*A8121AA5	Timer Board C-3036
*A8121AA6	Timer Board C-3036
A8121AA7	Timer Board
A8121AA8	Timer Board
A8121AA9	BM Timer Board
A8121AB1	Timer Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

A8121AE1	Hall Stack Board
*A8121AH2	PC Board
*A8121AH6	BP-MRVF PC Board
A8121AL1	PC Board
*A8121AL10	PC Board, Timer C-3041
*A8121AL12	MRVF-PC Board
A8121AL13	MRVF-PC Board
A8121AL2	PC Board BM
A8121AL23	MRVF PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

A8121AL24

PCB, Timer Board

A8121AL3

PC Board

A8121AL4

PC Board, Timer Board

A8121AL5

Timer Board C-3036

A8121AL7

Timer Board

A8121AR1

MRVF-PC Board

A8121AT1

Buffer Board

\*A8121AW1

GMI-P/C Board R/F

\*A8121AY1

HFI PCB for LRVM

A8121B2

PC Board

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A8121BM1	MPGC-PC Board
A8121BS1	MPGC-PC Board
A8121BT1	MPGC-PC Board
A8121CB1	MPGC-PC Board
A8121CB3	MPGC-PC Board
*A8121CB4	MPGC PC Board En50306
A8121D1	PC Board, BP
A8121D2	PC Board, BP
A8121D3	PC Board

\* Currently repair only.

**OTIS**

***Otis PC Boards******Unitec Part No.******Description***

A8121D4

PC Board, BM

A8121D5

PC Board

\*A8121DY2

LRS3 Wiring Tester with Cables

A8121E4

Double Gong PCB

A8121P1

Com1 Printed Circuit Board

A8121Y1

Timer Board

A8121Y2

Timer Board

A8121Y3

MRVF PC Board

\*A8124AL1

PC Board

\*A8124PB1

Repair and Return PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A8124UN	PC Board, Universal Board
*A8124UN402	PC Board, Universal Circuit Board
*A8124UN454	PC Board, Universal Circuit Board
*A8124UN54	PC Board
*A8126A1	Power Supply
A8128DP1	Counter PC Board
A8200AV1	IDS Temp Sensor PC Board
A8200AW1	Velocity Loop PC Board
*A8200BT2	Pet PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

A8200CA4

Processor Board, E401 Top-of-Car Interface Box

A8200EB1

PCB Speech Board

\*A8200EB3

ADPCM Speech Board w/o Chips

A8200EB4

Communications/ADPCM Speech Board

A8201P1

Circuit Board

\*A8202H1

PC Board

A8203A1

PC Board

\*A8203A3

PC Board

\*A8211A1

PC Board

\*A8211B1

PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A8211C1	PC Board
*A8211D1	PC Board
*A8211D2	Freq & Amp Board
*A8211E1	PC Board
*A8211F1	PC Board
*A8211F2	PC Board
*A8211F3	MRVF Board Buffer
A8212A1	IEE Retrofit
*A9673AF2	PC Board

\* Currently repair only.

**OTIS**

***Otis PC Boards******Unitec Part No.******Description***

*A9673W3	PC Board
*A9693A3	Limited Car Board
A9693AE1	PC Board
A9693D1	PC Board, Ring Car Board
A9693D2	Ring Car PC Board
A9693F1	PC Board, Switch Mod Assm.
*A9707C1	PC Board, Motherboard
A9707C3	PC Board, Motherboard
*A9707C4	PC Board, Motherboard
A9708AH1	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*A9708BJ1	Power Pack
A9708BJ3	Thyristor Panel
A9708BJ4	Thyristor Panel
*AAA00639AAE002	Computer, PCAT Model, EMS Configured
*AAA21000C2	KEC Group Power Supply on Adapter Plate
AAA21430L1	Upgraded HT200750-1 PVT
*AAA26800ACB001	PC Board
AAA26800AHJ1	PC Board, Black Belt Operator
AAA26800AJV1	E411MMS Motion Logic III Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

AAA26800AJV2

E411MMS Motion Logic III Board

AAA26800ALQ1

Speed Control Board

AAA26800KC1

Ring Car Board (RCB), 1A

\*AAA26800KJ2

Door Interface Sub-System (DISS), E311/411M

\*AAA26800KJ4

Door Interface Sub-System (DISS), Modified  
AAA26800NP1 PCB Kit

\*AAA26800KK2

Advanced Door Interface Sub-System, E311/411M

\*AAA26800KK3

Advanced Door Interface Sub-System,  
Modified AAA26800NR1 Board

\*AAA26800KK4

Advanced Door Interface Sub-System, Kit:

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

	Includes AAA26800KK3 Board
AAA26800KX1	PC Board, Controller Interface
AAA26800LB1	PC Board, Loadweighing Sub-System (LWSS Processor)
AAA26800MT1	PC Board, Modernization Remote Station Extender
*AAA26800MZ1	LRVM Relay Board
AAA26800NP1	DISS Board
*AAA26800NR1	ADISS Board
AAA26800NZ1	Controller Interface Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

AAA26800QM1

CPU

AAA26800RE1

Card, Regulator CB Based Power Supply

AAA26800RV1

PC Board Assembly, Hall Lantern

AAA26800RV2

PC Board Assembly, Hall Lantern

AAA26800SD1

ICA Term. Hall Lantern PC Board Assembly

AAA26800UA1

Readout, Alphanumeric

AAA26800VT1

Electronic Door Restrictor

AAA639CH1

Drive, Hard Disk, Internal, EIDE Interface

\*AAA8126K1

Power Supply Assembly

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

AAB22439E2

Tape Reader Subassembly

AAB22439E4

Assembly, Tape Reader 335 MW

AAB22439E5

Assembly, Tape Reader

AAB22439E6

Assembly, Tape Reader

ABA25000C1

COP II CPU/Pocket/Handle Sub-Assm., E401

ABA26800AAT002

ELD Remote Station Interface Board Assembly

ABA26800AJV1

E411MMS Motion Logic III PC Board

ABA26800AJV2

E411MMS Motion Logic III PC Board

ABA26800HT1

ELD Buffer Board and Assembly

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

ABA26800KJ4

DISS Board

\*ABA26800KK3

ADISS Board w/Loadweighing Device

ABA26800KK4

ADISS Board w/Loadweighing Device

ABA26800MZ1

LRVM Relay Board

ABA26800TH1

Remote Station Board Assembly

ABA26800TV1

Remote Station Board Assembly

\*ABA26800XH1

PCB Motion Logic/E411MMS MLB III

ABA26800ZZ1

ADPCM Speech Board

ABA26800ZZ4

PC Board, Speech - Male Voice

ACA21290BA2

OVF Drive, NAO, 120 Amp, 480 Volt

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

ACA21290BA4

OVF Drive, ETO, 120 Amp, 480 Volt

ACA21290BJ2

Assembly, OVF Drive, 90 Amp, 480 Volt

ACA21290BM1

Assembly, OVF Drive, 210 Amp, 480 Volt

ACA21290M1

Substituted to ACA21290BAZ-UNITEC

ACA21290Y4

Substituted to ACA21290BJZ-UNITEC

\*ACA21290Y5

Substituted to ACA21290BJZ-UNITEC

\*ACA21290Y6

Substituted to ACA21290BJZ-UNITEC

ACA26800XH1

Motion Logic Board (MLB III), E411MMS

\*ACA26800XH2

Motion Logic Board (MLB III), E411MMS

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

ADA21290AK2

Assembly, OVF Drive, OVF 70 Amp, 480 Volt

\*ADA21290AP2

Assembly, OVF Drive, 140 Amp, 240 Volt

ADA26800MB1

Drive Upgrade - Contact UNITEC

\*ADA26800MB5

Substituted to ACA21290BM1 - Contact UNITEC

ADA26800RB1

High Voltage Interface Board

ADA26800VF1

High Voltage Interface Board

\*AEA26800AAP001

Control Board

\*AEA26800AAP002

Control Board

\*AEA26800AAP004

Tape Reader PC Board

AEA639AZ2

Machine Room Int. w/o Ring Card Board II or 32 Channel

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

	I/O Board
AFA26800AAP001	Control Board
AFA26800AAP002	Control Board
AFA26800AAS001	PC Board, ELD Interface Assembly
AFA26800UD1	High Voltage Interface Board
AFA26800UD2	High Voltage Interface Board
AFA26800UD3	High Voltage Interface Board
*AYXC9708AE1	Wm-PC Board 215 D
*B7048AD1	Power Supply Assembly
B8110C1	Circuit Board

\* Currently repair only.

**OTIS**

*Otis PC Boards*

<i>Unitec Part No.</i>	<i>Description</i>
B8110C2	PC Board
B8110G1	PC Board
*B8111A1	PC Board
B8111A2	PC Board
B8111A3	PC Board
B8111C1	PC Board
B8111C2	PC Board
B8111C3	PC Board
*B8112A1	Repair and Return PC Board
B8112A3	PC Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

B8112B1	PC Board
B8112B3	PC Board
B8112C1	PC Board
B8112H2	PC Board
B8113J1	PC Board (CV4)
*B8113J2	PC Board
*B8113J3	PC Board (CV4)
*B8113J4	PC Board
B8113J5	PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

\*B8113K1

PC Board

B8113K3

PC Board

\*B8113K5

PC Board

B8114G1

PC Board

\*B8115B1

PC Board

B8115B2

PC Board

B8115B3

PC Board

B8117B1

PC Board

B8121AH1

Vacuum Fluorescent &amp; Speech (VFSB) PC

\*B8121AH2

PC Board, Vacuum Fluorescent w/Program Chip

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*B8121AM1	PC Board
*B8121AX1	PC Board EMI
*B8121BC1	PC Board
B8121BJ1	PC Board, Touch Tone Interface
B8121BK1	MPGC PC Board
B8121BM1	MPGC PC Board
B8121BM3	MPGC Board
*B8121BM5	Universal Input Board
B8128DR1	SC I/O Board Assembly

\* Currently repair only.

**OTIS**

*Otis PC Boards*

<i>Unitec Part No.</i>	<i>Description</i>
B8128DR2	PC Board
B8200BT1	Pet Board
B8200BT2	Pet Board
B8200BT3	Pet Board
B8211D1	VF-Freq & Amp PC Board
*B8211E1	EMI Board for MRVF
B9693A3	Limited Car Board
B9693AE1	Remote Station Extender PC Board
*B9693MB1	DISS Board
B9693MG1	ADISS Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

B9693MG2

ADISS Board

\*B9708AB1

PC Board

\*B9708AD2

PC Board

B9708AF1

PC Board

B9708BF1

Impulse Trans P/C

B9708BF2

Impulse Transformer Board

B9708BF3

Impulse Transformer Board

\*B9708BJ2

Thyristor Panel

B9708BK1

MRV-Gamma 160S Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

*B9708BM1	Gamma D Processor Board
*B9708BM2	Processor Board
B9708BN1	Gamma I/O Board
B9708BN2	I/O Board
*BA-AS-100797	LCRT CPU, Repair Part Number Only JWS
*BS-AS-100797-1	Computer Assm. 1-Grp
BSAS800485-3	Slave REM Board
*C0NC-392	Opto Reader Circuit Board 3.0
C621G1	Carrier Power Supply
C628B1	Battery Charger

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

C8112B1	PC Board
C8112B10	PC Board
*C8112B11	PC Board
*C8112B2	PC Board
C8112B3	PC Board
C8112B4	PC Board
*C8112B7	PC Board
C8112B8	PC Board
C8113K5	Circuit Board
C8114G1	PC Board

\* Currently repair only.

**OTIS**

***Otis PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>Description</i></b>
C8121AM1	Receiver Board
C8121AX1	LRVM Relay Board
*C8121AX2	LRVM Relay Board
C8121CH1	PWM Board
C8121CH2	PWM Board
C8121DB1	PC Board
*C8211B1	MRVF Board
*C8211C1	MRVF Board
C8211F1	PC Board, EN50150
C8211F2	PC Board, EN50150

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

C8211F3	PC Board, EN50150
*C9673T4	PC Board
C9693A3	Limited Car Board
C9693MB1	DISS Board
C9693MB2	DISS Board
*C9708AD1	Logic Board
C9708AD2	Logic Board
*C9708AE1	PC Board
C9708BM2	Processor Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

D8121BC1

LRS3 Board (Altek)

D8121BX1

9-Channel Board

D8121BX2

9-Channel Board

D8211B1

VF-Inverter Control Board Assembly

\*D8211C1

VF-Speed Control Board

\*D8211E1

VF-Speed Dictation Board

\*D9673T4

PC Board

\*D9708AE1

Gamma 160 Board

E8121BE1

Button Interface Module Board

E8121DB1

Microcontroller Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

E8211C1

VF Speed Control Board

E8211E1

VF Speed Dictation Board

\*E9708AE1

Speed Control Board

F8121BC1

Microcontroller Board

\*F9708AE1

PC Board

F9708AE3

Speed Control Board

\*GCA21270A1

Ring Car / ICSS Board

\*GCA21270A2

Ring Car Board II (RCBII)

\*GCA21270A3

Ring Car Board II (RCBII)

\* Currently repair only.

**OTIS**

***Otis PC Boards******Unitec Part No.******Description***

GCA23550B1

RS4 Gong Board

GDA21270A4

PC Board

\*GEA21270A1

Ring Car Board II

GEA21270A3

Ring Car Board II

\*GFA21270A3

Ring Car Board II

GGA21270A3

Ring Car Board II

GGA21270A6

Ring Car Board II

GHA21270A3

Ring Car Board II

\*HT200710-2

Primary Position Transducer (PPT)

\*HT200750-1

Transducer, Primary

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

HT201450-1	Power Supply Door Motor
*HT201723-1	Group I/O Board, Full
HT201723-2	Group I/O Board, Full
*HT201725-1	Power Amp I/O Board
*HT201725-2	Power Amp I/O Board
*HT201725-3	Power Amp I/O Board
*HT201726-1	PC Board
HT201727-1	PC Board
*HT201731-3	PC Board

\* Currently repair only.

**OTIS**

***Otis PC Boards******Unitec Part No.******Description***

HT201731-4

Cab I/O Assm. Board

HT201732-1

PC Board Assm.

HT201732-4

Communication I/O Board

HT201732-6

Communication I/O Board Assembly

HT201732-8

Communication I/O Board

HT201733-1

Transducer I/O Board

HT201734-3

PC Board

\*HT201734-5

Relay I/O Board, (E-101 w/Ward-Leonard Control)

\*HT201734-6

Relay I/O Board

HT201736-1

Bus Terminator Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

HT201739-1	Power Amp Board
HT201781-1	PC Board
*HT201781-2	Power Supply
*HT201788-1	Processor Board
HT201788-3	PC Board, E401 CPU
*HT202088-2	Relay I/O Board
*HT203101-1	Relay I/O Board
HT203101-2	Relay I/O Board
HT203102-1	Generator Field I/O Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

HT203103-1

Car Fixtures I/O Board

\*HT203193-3

Power Supply

HT204327-1

Bus Terminator Board

\*HT204349-3

PC Board, E401 CPU Board Assembly Processor

HT204349-4

PC Board, E401 CPU Board Assembly Processor

HT204411-2

Power Amp

HT205925-1

Power Amp I/O

\*HT205925-2

PC Board, Engr Build

HT206020-2

Power Amp LA/RB

HT206412-1

Power Amp

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*HT206481-1	PC Board, Processor
HT206481-3	PC Board, Processor Board Assembly
HT206481-4	PC Board, Processor Board Assembly
J06840NS1	Relay Unit PC Board
*LA46S1606-0030	Lo Volt Power Supply
LA46S1607-1050	12 SCR Main/Aux Board
LA46S1607-1060	PC Board, 12 SCR Main/Aux
*LA46S1607-1080	PC Board, 12 SCR Main/Aux
LA46S1677-0070	Gate Firing PC Board

\* Currently repair only.

**OTIS**

*Otis PC Boards*

<i>Unitec Part No.</i>	<i>Description</i>
LA46S1692-0030	Zero Current Detector
LA46S1692-0040	Zero Current Detector
LA46S1692-0050	Zero Current Detector
LA46S1692-0060	Zero Current Detector
LA46S2206-0013	PC Board, Elevator Control
LA46S2263-0020	Power Supply PC Board for Modmaster SCR Drive
*LA46S2263-0020-MR	Power Supply PC Board for Modmaster SCR Drive
*LA46S2284-0010	E101 Heat Sink Assm.
*LA46S2284-0020	SCR Bridge Assm.
*LA46S2284-0030	SCR Bridge Assm.

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*LA46S2284-0040	Bridge Assm. SCR
*LA46S2284-0050	Bridge Assm. SCR
LA46S2284-0060	SCR Bridge Assm.
*LA46S2285-0010	Base Assm., Basic
LA46S2438-0010	Heat Sink Assm.
LA46S2438-0020	Heat Sink Assm.
LA46S2438-0030	Heat Sink Assm.
LA46S2438-0040	Heat Sink Assm.
LA46S2438-0050	Heat Sink

\* Currently repair only.

**OTIS**

***Otis PC Boards******Unitec Part No.******Description***

LA46S2438-0060

Heat Sink Assm.

\*LA46S2438-0070

E401 Bridge Assm.

LA46S2439-0010

PC Board, 12 SCR Cont

\*LA46S2439-0040

PC Board, 12 SCR, Modmaster

LA46S2439-0130

12 SCR PCB (165/509 V) Modmaster SCR Drive

LA46S2440-0010

PC Board, Elevator Control

LA46S2441-0010

PC Board, Gate Firing

LA46S2442-0010

Voltage Divider Board

\*LA46S2442-0080

Voltage Divider Board

\*LA46S2442-0130

Voltage Divider Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

*LA46S2442-0140	Voltage Divider Board
*LA46S2442-0200	PC Board
*LA46S2442-0220	Voltage Divider Board
*LA46S2442-0460	Voltage Divider Board
*LA46S2442-0470	Voltage Divider Board
*LA46S2442-0480	Voltage Divider Board
*LA46S2442-0490	Voltage Divider Board
*LA46S2442-0500	Voltage Divider Board
*LA46S2442-0520	Voltage Divider Board

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

*LA46S2442-0530	Voltage Divider Board
LA46S2477-3020	Regulator PCB for Modmaster SCR Drive
LA46S2484-0020	Field Regulator Power Board
LA46S2485-0021	Field Regulator Signal Board Modmaster
*RB326-010-50	Suppressor Board R
*RB326-010-51	Suppressor Board R
RB326-010-52	Suppressor Board R
*RB326-010-53	Suppressor Board
RB326-010-54	Suppressor Board
RB326-010-55	Suppressor Board

\* Currently repair only.

### *Otis PC Boards*

#### *Unitec Part No.*

#### *Description*

RB326-010-70	Suppressor Board
RB326-010-71	Suppressor Board
RB326-010-72	Suppressor Board
RB326-010-73	Suppressor Board
RB326-052-1	Heat Sink Assm. R
RB326-052-2	Heat Sink Assm. R
RB326-052-3	Heat Sink Assm. R
RB326-052-4	Heat Sink Assm.
*RB326-052-5	Heat Sink Assm.

\* Currently repair only.

**OTIS**

*Otis PC Boards**Unitec Part No.**Description*

\*RB362-302-01

Emergency Exciter Field Circuit

RB560-275-05

Control Board /9

RB560-275-2

Control Board

RB560-276-02

Gate Board

RB560-276-05

Gate Board

SA14-193-7

PC Board

SA14-193-770-567

DC Contactor, 125 V, w/3ty7 Auxiliary Contact,  
(Louis-Allis Drive), E411

SA14-193-770-568

DC Reversing Contactor, 125 V, w/3ty7 Auxiliary Contact,  
E411 w/Louis-Allis Drive~~SA14-193-770-570~~~~DC Reversing Contactor w/3ty7 Auxiliary Contact,~~

\* Currently repair only.

***Otis PC Boards***

***Unitec Part No.***

***Description***

	E401 w/Louis-Allis Drive
SA14-193-770-571	DC Reversing Contactor, 250 V, w/3ty7 Auxiliary Contact (Robicon Drive) 401
SA14-193-770-572	DC Contactor, 250 V Coil, 3ty7 Auxiliary Contact, E401 w/Louis-Allis Drive
*YXG0630D1	Relay Assembly
YXG0630D2	Relay Assembly
YXG0630D3	Relay Assembly 110/220 V
*2700CAA5	Drive w/o Logic - Replaced with 10260P10
2700CAA6	Logic Assembly - Replaced with 10260P10

*Otis PC Boards**Unitec Part No.**Description*

10260P10

Spec 60 Drive

\* Currently repair only.

***Rēliance PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*RELI0-51874	0-51874	SSCA Board
*RELI0-51874-2	0-51874-2	SSCA Board

\* Currently repair only.

**RELIANCE**



### *Schindler PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*SCHD223824	223824	STDC Board for EPOCH II
SCHD223825	223825	STDC Board for EPOCH II
SCHD224213	224213	SHVM Board
SCHD224371	224371	Comm Daughter Board, Car
SCHD225053	225053	Comm Daughter Board, Car
SCHD225054	225054	Comm Daughter Board, Disp
*SCHD225088	225088	SC I/O Board
SCHD225094	225094	SFCB Board
SCHD225723	225723	SMTV Board

\* Currently repair only.

**SCHINDLER**

**SCHINDLER***Schindler PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
SCHD225515	225515	SMHC Processor Board
SCHDSME438517	SME438517	Comb Light Ass., 24 V, 60 Hz LED
SCHDSSA897200	SSA897200	LFTNG Solenoid

*Thames Valley PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*THAMSP27180-CPU2D	SP27180-CPU2D	Thames Valley CPU Board

\* Currently repair only.

**THAMES VALLEY**



### *Thyssen-Krupp PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*THSN6300KC2	6300KC2	Aux. Power Supply, 24 VDC TAC20
*THSN6300KC3	6300KC3	Aux. Power Supply, 115 VAC TAC22
*THSN6300KC4	6300KC4	Aux. Power Supply, 150 VDC, TAC22
*THSN6300KC5	6300KC5	Aux. Power Supply, 48 VDC, TAC22
*THSN6300KC6	6300KC6	Aux. Power Supply, 48 Group
*THSN9782709	9782709	Aux. Power Supply, 24 VDC,

\* Currently repair only.

**THYSEN-KRUPP**



### *U.S. Elevator PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
USEL145-05200-300	145-05200-300	Rectifier Door Board
USEL146-05010-300	146-05010-300	A2 Computer Board for MP-1230 Hydro
USEL146-05011-300	146-05011-300	A2 Computer Board for MP-1230 Hydro
USEL146-05030-300	146-05030-300	A3 Option Board for MP-1230
USEL146-05040-300	146-05040-300	Cartop Control Board for U.S. MP-1230 Hydro
USEL146-05060-300	146-05060-300	Power Sup. for U.S. MP-1220 and MP-1230 Units
USEL146-05080-300	146-05080-300	Personality Board for U.S. MP-1230 Hydro

**U.S. ELEVATOR**

## U.S. ELEVATOR

### *U.S. Elevator PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
USEL146-05090-300	146-05090-300	Power Sup. for U.S. MP-1220 and MP-1230 Units
USEL146-05200-300	146-05200-300	Mother Board for U.S. MP-1220
*USEL146-05220-300	146-05220-300	A2 Computer Board for MP-1220
USEL146-05221-300	146-05221-300	A2 Computer Board for MP-1220
*USEL146-05230-200	146-05230-200	A3 / A4 / A5 Input/Output
USEL146-05230-300	146-05230-300	A3-A5 Board, MP-1220
USEL146-05260-300	146-05260-300	Power Relay Motherboard for U.S. MP-1220
USEL146-05280-300	146-05280-300	Car Top Mother Board

\* Currently repair only.

### *U.S. Elevator PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
USEL146-05285-300	146-05285-300	Multiplex Car Top Mother Board
USEL146-05286-300	146-05286-300	I/O Board, Input Buffer
USEL146-05287-300	146-05287-300	I/O Board, Output Latch
USEL146-05290-300	146-05290-300	Personality Board for U.S. MP-1220
USEL146-05300-300	146-05300-300	Mother Board for U.S. MP-1230 Hydro
USEL146-05600-300	146-05600-300	Buss Board Model Ascension 1000
USEL149-00001-001	149-00001-001	Varitron SS-D1 Assembly
*USEL153-05007-300	153-05007-300	Earthquake DET Board
*USEL140-00040-007	440-00040-007	Bridge Rectifier Board

**U.S. ELEVATOR**



### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST1185C11H01	1185C11H01	DN1 Corridor Cage
*WEST1185C12H01	1185C12H01	DN2 Car Controller
*WEST1185C13H01	1185C13H01	DN3 Car Controller
*WEST1185C13H02	1185C13H02	DN3 Car Controller
*WEST1185C27-A	1185C27-A	FS1 Board
*WEST105C501	105C501	Timer
WEST1185C30H01	1185C30H01	IT1 Board
*WEST1185C31H01	1185C31H01	IT2 Board
WEST1185C32H01	1185C32H01	IT3-SMF3 West. Mark 5 Board

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST1185C33H01	1185C33H01	MC1 Car Controller
*WEST1185C42H01	1185C42H01	PE1 Detector
*WEST1185C43H01	1185C43H01	PE2 Board
*WEST1185C43H02	1185C43H02	PE2 Board
WEST1185C43H03	1185C43H03	PE2 Board
WEST1185C43H04	1185C43H04	PE2 Board
*WEST1185C45H01	1185C45H01	PRI Car Controller
*WEST1185C63H01	1185C63H01	TM2 Car & Corridor Contr
*WEST1185C64H01	1185C64H01	TM3 Board
*WEST195501H01	195501H01	Timer

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST195C500H01	195C500H01	1 Min Timer
WEST195C501H01	195C501H01	Timer
*WEST195C502	195C502	MG Timer Board
WEST195C502G01	195C502G01	MG Timer
*WEST195C503	195C503	Timer Board, MT3
WEST195C503G01	195C503G01	MT3 Dual Timers
*WEST195C503G02	195C503G02	Timer, MT3
*WEST195C503G03	195C503G03	MT3 Dual Timers
WEST195C503H01	195C503H01	Timer
* Currently repair only. WEST196C584G01	196C584G01	SP1 Board

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST196C584H01	196C584H01	SP1 Mark IV-Selectomatic-SMF2
*WEST196C585G01	196C585G01	SP2 Board
*WEST196C585H01	196C585H01	SP2 (MD2 Drive)
*WEST196C587H01	196C587H01	Phase Lock Oscillator Older version
*WEST196C595G01	196C595G01	MPS (Power Supply) Used on West. SMF2-MACH IV
*WEST196C596G01	196C596G01	Gate Driver—Mark IV-Selectomatic
*WEST196C596H01	196C596H01	MGD Gate Driver
*WEST196C597G01	196C597G01	West Mark IV-Selectomatic

\* Currently repair only.

### *Westinghouse PC Boards*

*Unitec Part No.*

*OEM Part No.*

*Description*

\*WEST196C597H01

196C597H01

SMF2-DESIGN PC

West Mark IV-Selectomatic  
SMF2-DESIGN PC

\*WEST196C628H01

196C628H01

ER Amplifier

\*WEST382D281G01

382D281G01

125 V Power Supply

WEST382D282G01

382D282G01

+5 V, +15 V, -15 V, DC Power  
Supply Assembly

WEST382D282G02

382D282G02

5 V Power Supply

WEST477C843H

477C843H

ER9 Amplifier Board for Elec-

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST477C977H02	477C977H02	tronic Reg. Amplifier Board
WEST477C977H03	477C977H03	ER8/ER9 Amplifier Board for Electronic Reg.
*WEST478C315	478C315	Timer
WEST478C315G01	478C315G01	Timer Y-Delta 5 Min
*WEST5196D35H	5196D35H	ER10 Amplifier Board for Elec- tronic Reg.
WEST6916C23G01	6916C23G01	SBC-88/25 for Car B6
WEST6916C23G02	6916C23G02	SBC-88/25, Dispatcher W-Slot, B7

\* Currently repair only.

***Westinghouse PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
WEST6916C23G03	6916C23G03	SBC-88/25 for Group Comm. to Cars 1-4 B7
WEST6916C23G04	6916C23G04	SBC-88/25, Dispatcher to Remote
WEST6916C23G05	6916C23G05	SBC-88/25, Dispatcher Comm. to Cars 5-8
*WEST6916C23G06	6916C23G06	SBC-88/25, Dispatcher Comm. to Cars 5-8
*WEST6916C23G07	6916C23G07	SBC-88/25, Dispatcher Comm. to Cars 5-8
WEST6916C24G01	6916C24G01	SBC Board (Car)
* Currently repair only WEST6916C24G02	6916C24G02	SBC Board (Dispatcher)

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST6916C24G03	6916C24G03	SBC Board (Comm Car 0-3)
*WEST6916C24G04	6916C24G04	SBC Board (Traffic Dir.)
*WEST6916C24G05	6916C24G05	SBC Board (Comm Car 4-7)
WEST6916C25G01	6916C25G01	SBX-351 for Car
WEST6916C25G02	6916C25G02	SBX-351 for Last Car
WEST6916C25G03	6916C25G03	SBX-351 for Group to Cars 1-4
*WEST6916C25G04	6916C25G04	SCM, SBX-351 for Dispatcher to Remote
WEST6916C25G05	6916C25G05	SCM, SBX-351 for Group to Cars 5-8
WEST6919C50G01	6919C50G01	RAM Module EPOCH SBC 88/25

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST7267C08G01	7267C08G01	TDC Board
*WEST998C002H11	998C002H11	MGI Board EPOCH I Controllers
*WEST998C002H12	998C002H12	MGI Board for EPOCH I Controls
WEST998C002H14	998C002H14	MGI Board for EPOCH I Controls
*WEST998C009H11	998C009H11	PLO "Newer Version"
*WEST998C011H11	998C011H11	DN1 Corridor Cage
*WEST998C011H12	998C011H12	Corridor Control
* WEST998C011H23	998C011H23	DN1 West. Mark 5 Board

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST998C012H11	998C012H11	DN2 Car Controller
*WEST998C012H12	998C012H12	DN2 Car Controller
*WEST998C012H13	998C012H13	DN2 Car Controller
*WEST998C012H16	998C012H16	DN2 Car Controller
*WEST998C012H26	998C012H26	DN2 Car Controller
*WEST998C012H27	998C012H27	West. Mark 5 Board DN2
*WEST998C015H11	998C015H11	DN3 Car Controller
*WEST998C015H21	998C015H21	DN3 Car Controller
*WEST998C015H22	998C015H22	DN3 Car Controller
*WEST998C015H23	998C015H23	DN3 Car Controller

\* Currently repair only.

### *Westinghouse PC Boards*

#### *Unitec Part No.*

#### *OEM Part No.*

#### *Description*

*WEST998C015H33	998C015H33	West. Mark 5 Board DN3
*WEST998C016H33	998C016H33	DS1 Board
*WEST998C027H11	998C027H11	FS1 Car Controller
*WEST998C027H12	998C027H12	FS1 Car Controller
*WEST998C027H22	998C027H22	FS1 Car Controller
WEST998C027H23	998C027H23	FS1 Mark V Printed Circuit Card
WEST998C027H34	998C027H34	West. Mark 5 Board FS1
WEST998C030H27	998C030H27	Mfr. Board, EPOCH II
*WEST998C031H01	998C031H01	IT2 Car Controller

\* Currently repair only.

~~WEST998C031H11~~

~~998C031H11~~

~~IT2 Board~~

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
WEST998C042H11	998C042H11	PE1 Board
*WEST998C045H11	998C045H11	PR1 Car Controller
*WEST998C045H12	998C045H12	PR1 Car Controller
*WEST998C045H22	998C045H22	West. Mark 5 Board PR1
*WEST998C052H23	998C052H23	SM2 Board
*WEST998C063H11	998C063H11	TM2 Board
*WEST998C063H12	998C063H12	TM2 Board
*WEST998C063H13	998C063H13	TM2 Board
WEST998C063H23	998C063H23	TM2 West. Mark 5 Board
*WEST998C063H24	998C063H24	TM2 Board

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST998C065H11	998C065H11	TMJ Board
*WEST998C068H11	998C068H11	IEE Car Station
*WEST998C068H12	998C068H12	IEE (2-Trn)
*WEST998C076H11	998C076H11	DDD Boards
WEST998C076H12	998C076H12	DDD Boards
*WEST998C076H13	998C076H13	DDD Boards
WEST998C076H14	998C076H14	DDD Board for Selector Pulse on EPOCH I Contr.
*WEST998C080H11	998C080H11	MGA Geared Board
* Current * WEST998C080H12	998C080H12	MGA Geared Board

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST998C080H13	998C080H13	MGA Geared Board
WEST998C080H14	998C080H14	MGA Board for EPOCH I Controls Starter Panel
WEST998C080H15	998C080H15	MGA Board
*WEST998C088H11	998C088H11	West. Mark 5 Board Rex
*WEST998C088H12	998C088H12	REX Board
*WEST998C090H11	998C090H11	IO2 Board for EPOCH I Controls
WEST998C090H12	998C090H12	IO2 Board for EPOCH I Controls
WEST998C091H11	998C091H11	IO6 Board for EPOCH I Controls
WEST998C091H12	998C091H12	IO6 Board for EPOCH I Controls

\* Currently repair only.

### *Westinghouse PC Boards*

#### *Unitec Part No.*

#### *OEM Part No.*

#### *Description*

WEST998C092H11

998C092H11

IO8 Board for EPOCH I Controls

WEST998C092H12

998C092H12

IO8 Board for EPOCH I Controls

WESR998C096H22

998C096H22

RTC Board

WEST998C102H11

998C102H11

IOT Board for EPOCH I Controls

WEST998C102H12

998C10212

IOT Board

\*WEST998C102H14

998C102H14

IOT Board for EPOCH I Controls

\*WEST998C108H11

998C108H11

ERA Amp Board

WEST998C108H12

998C108H12

ERA Amp Board

\*WEST998C109H11

998C109H11

ERA Amp Board

\* Currently repair only.

WEST998C110H11

998C110H11

ERB Amp Board

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
WEST998C110H12	998C110H12	ERB Amp Board
WEST998C113H11	998C113H11	EPOCH I TB3
*WEST998C117H11	998C117H11	BBI Board
WEST998C120H11	998C120H11	DMM Board
*WEST998C123H11	998C123H11	HPI Board
*WEST998C131H11	998C131H11	MEM Board
*WEST998C140H13	998C140H13	MGI Board
*WEST998C142H11	998C142H11	MGA Geareless Board
*WEST998C142H12	998C142H12	MGA Gearless Board
*WEST998C142H13	998C142H13	MGA Gearless Board

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST998C142H14	998C142H14	MGA Gearless Board
*WEST998C145H11	998C145H11	MPH Board
*WEST998C145H22	998C145H22	MPH Board
*WEST998C145H23	998C145H23	MPH Board
WEST998C145H24	998C145H24	MPH PC Board for Westinghouse MPH Hydro
*WEST998C145H25	998C145H25	MPH Board
*WEST998C146H11	998C146H11	HRM Board
*WEST998C146H21	998C146H21	HRM Board
* Current WEST998C146H22	998C146H22	HRM Board

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST998C147H12	998C147H12	DCB PC Board for Westinghouse MPH Hydro
WEST998C147H15	998C147H15	DCB PC Board for Westinghouse MPH Hydro
*WEST998C148H11	998C148H11	FCB Board
*WEST998C148H12	998C148H12	FCB Board
*WEST998C148H13	998C148H13	FCB Board
WEST998C148H14	998C148H14	FCB Board
WEST998C148H15	998C148H15	FCB PC Board for MPH Hydro
WEST998C148H25	998C148H25	FCB PC Board for MPH Hydro

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
WEST998C148H26	998C148H26	FCB PC Board for MPH Hydro
WEST998C153H13	998C153H13	MPT PC Board for Schindler EPOCH
WEST998C153H14	998C153H14	MPT PC Board for Schindler EPOCH
WEST998C153H15	998C153H15	MPT PC Board for Schindler EPOCH
WEST998C169H11	998C169H11	DPR Board for EPOCH II/MPH Equip.
WEST998C177H11	998C177H11	HR2 Board for Westinghouse MPH Hydro

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST998C187H11	998C187H11	MHC Board
*WEST998C187H12	998C187H12	MHC PC Board, MPH-2
WEST998C187H13	998C187H13	MHC Board
*WEST998C187H14	998C187H14	MHC PC Board for Westinghouse MPH II Hydro
WEST998C187H24	998C187H24	MHC PC Board for Westinghouse MPH II Hydro
WEST998C187H25	998C187H25	MHC Board for Westinghouse MPH II Hydro
WEST998C187H26	998C187H26	MHC Processor Board

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
WEST998C188H11	998C188H11	IOX Board for Westinghouse MPH II Hydro
*WEST998C189H12	988C189H12	RMH Board
*WEST998C189H13	988C189H13	RMH Board
*WEST998C189H14	988C189H14	RMH Board
*WEST998C190H12	998C190H12	RMH Board CSA
*WEST998C197H11	998C197H11	MTV Board for EPOCH 2
WEST998C197H12	998C197H12	MTV Board for EPOCH II / Mi-conic VA Equip.

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
WEST998C197H13	998C197H13	MTV PC Board for EPOCH II/Miconic VA Equip.
WEST998C198H11	998C198H11	Digital PI Board, MPH-II
*WEST998C198H12	998C198H12	Digital PI Board, MPH-II
*WEST998C198H13	998C198H13	Digital PI Board, MPH-II
*WEST998C198H14	998C198H14	Digital PI Board, MPH-II
*WEST998C208H11	998C208H11	EPG Board
*WEST998C209H15	998C209H15	IBP Board
WEST998C212H11	998C212H11	FCM PC Board for EPOCH II / MPH II Equip.

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
WEST998C214H11	998C214H11	HVM PC Board for EPOCH II / MPH II Equip.
WEST998C214H12	998C214H12	HVM PC Board for EPOCH II / MPH II Equip.
*WEST998C214H25	998C214H25	High Voltage
WEST998C216H12	998C216H12	RMH Board
*WEST998C216H13	998C216H13	RMH Board
*WEST998C216H14	998C216H14	RMH Board
WEST998C216H15	998C216H15	RMH PC Board

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
WEST998C216H26	998C216H26	RMH Board
WEST998C216H27	998C216H27	RMH Board
WEST998C216H28	998C216H28	RMH Board
*WEST998C222H15	998C222H15	RMH PC Board
WEST998C225H12	998C225H12	VEC Board, Miconic AM VFAC
WEST998C245H11	998C245H11	PIB Board, Miconic 300A
WEST998C245H12	998C245H12	PIB Board, Miconic 300A
*WEST998C245H22	998C245H22	PIB Board
*WEST998C246H11	998C246H11	MIO Board, Miconic 300A
WEST998C246H12	998C246H12	MIO Board, Miconic 300A

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST998C247H11	998C247H11	CIO Board, Miconic 300A
WEST998C247H14	998C247H14	CIO Board, Miconic 300A
WEST998C254H12	998C254H12	MGS PC Board for EPOCH II/Miconic VA Equip.
*WEST998C272H11	998C272H11	REL Board, Miconic 300A
WEST998C272H12	998C272H12	REL Board
WEST998C272H13	998C272H13	REL Board
WEST998C276H22	998C276H22	TCP Board for EPOCH II
*WEST998C308H11	998C308H11	TDC Board for EPOCH II

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST999C001H11	999C001H11	TDC Door Controller Board
WEST999C001H12	999C001H12	TDC Door Controller Board
*WEST999C001H23	999C001H23	TDC Door Controller Board
WEST999C001H24	999C001H24	TDC Door Controller Board
WEST999C001H25	999C001H25	TDC Board
*WEST999C001H31	999C001H31	TDC Board for EPOCH II
WEST999C001H36	999C001H36	TDC Board for EPOCH II
*WEST999C003H11	999C003H11	TRM-B12 Board
*WEST999C003H12	999C003H12	TRM-B12 Board
WEST999C003H24	999C003H24	TRM-B12 Board

\* Currently repair only.

### *Westinghouse PC Boards*

<i>Unitec Part No.</i>	<i>OEM Part No.</i>	<i>Description</i>
*WEST999C003H25	999C003H25	TRM-B12 Board
WEST999C003H26	999C003H26	TRM-B12 Board
WEST999C225H25	999C225H25	MSR Board
*WEST999C422H11	999C422H11	WCF - Relay I/O Board for World Class System

\* Currently repair only.

**WESTINGHOUSE**

## WESTINGHOUSE

### *Westinghouse PC Boards*

*Unitec Part No.*

*OEM Part No.*

*Description*

\* Currently repair only.

### ***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
WRLD7000.9001	7000.9001	Stepper Board
WRLD7000.9002	7000.9002	Door Board
WRLD7000.9003	7000.9003	Diode Board
WRLD7000.9004	7000.9004	Level Board
*WRLD7000.9005	7000.9005	Speed Safety Board
WRLD7000.9007	7000.9007	7-Seg. Display Board
*WRLD7000.9010	7000.9010	Dual 7-Seg. Board
WRLD7000.9011	7000.9011	Rev. Phase Board
*WRLD7000.9012	7000.9012	GFC-IIA
*WRLD7000.9019	7000.9019	Counter Board

\* Currently repair only.

**WORLD ELEVATOR**

***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
WRLD7000.9030	7000.9030	Interface Board
*WRLD7000.9034	7000.9034	Dual Timer Board
*WRLD7101.0004	7101.0004	Door 4-Slot Board
*WRLD7101.9002	7101.9002	Power 4-Slot Board
*WRLD7101.9004	7101.9004	Door 4-Slot Board
*WRLD7101.9006	7101.9006	Car 4-Slot Board
*WRLD7101.9008	7101.9008	Top/Bottom 4-Slot Board
*WRLD7101.9010	7101.9010	Intermediate 4-Slot Board
*WRLD7101.9012	7101.9012	Option 4-Slot Board

\* Currently repair only.

### ***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*WRLD7101.9013	7101.9013	Duplex 3-Slot Board
*WRLD7101.9015	7101.9015	Logic 3-Slot Board
*WRLD7101.9023	7101.9023	Optical Leveling Board
*WRLD7101.9024	7101.9024	PI DriverBoard
*WRLD7101.9025	7101.9025	Rev. Phase Board
*WRLD7101.9030	7101.9030	Interface Board
*WRLD7101.9031	7101.9031	Rectifier Board
*WRLD7101.9032	7101.9032	Rectifier Board
*WRLD7101.9033	7101.9033	7-Seg Display Board

\* Currently repair only.

**WORLD ELEVATOR**

***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*WRLD7101.9035	7101.9035	Rectifier Board
*WRLD7101.9039	7101.9039	Rectifier Board
*WRLD7101.9043	7101.9043	Selector Leveling Board
*WRLD7101.9044	7101.9044	Rectifier Board
*WRLD7101.9048	7101.9048	LSP Board
*WRLD7103.9001	7103.9001	Power Relay Board
*WRLD7103.9002	7103.9002	Door Board
*WRLD7103.9004	7103.9004	DMC1 Board
*WRLD7103.9007	7103.9007	5 V and 12 V Power Supply
*WRLD7103.9008	7103.9008	Main Sensor Board

\* Currently repair only.

### ***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*WRLD7103.9009	7103.9009	Aux. Sensor Board
*WRLD7103.9011	7103.9011	Inter. Freedom Tool
*WRLD7103.9012	7103.9012	I/O Expansion Board
*WRLD7103.9016	7103.9016	CLC (New) Board
*WRLD7103.9017	7103.9017	Door Board
*WRLD7104.9003	7104.9003	Monitor Board
*WRLD7104.9007	7104.9007	MSI-I Power Board
*WRLD7104.9008	7104.9008	MSI-I Regulator Board
*WRLD7105.9008	7105.9008	I/O for TIII Board

\* Currently repair only.

**WORLD ELEVATOR**

***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*WRLD7105.9009	7105.9009	Main Sensor Board
*WRLD7109.9507	7109.9507	Univ. Timer Board
*WRLD7202.9001	7202.9001	ER 9 Amp Board
*WRLD7202.9002	7202.9002	ER 10 Amp Board
*WRLD7206.9002	7206.9002	MPH Board
*WRLD7206.9003	7206.9003	RHM Relay Board
*WRLD7206.9009	7206.9009	MHC Board
*WRLD7206.9012	7206.9012	I/OX Board
*WRLD7401.0004	7401.0004	Level Decode Board

\* Currently repair only.

### ***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*WRLD7401.9004	7401.9004	Level Swicth Board
WRLD7403.9009	7403.9009	Mother Board
*WRLD7412.9005	7412.9005	MIO Processor Board
*WRLD7412.9006	7412.9006	RHM Relay Board
*WRLD-7501-0042	7501-0042	GFC-IIA
*WRLD-7501-0043	7501-0043	GFC-IIA
*WRLD7601.1013	7601.1013	PI Display Board
*WRLD7601.9007	7601.9007	Input Board w/TB
*WRLD7601.9008	7601.9008	Input Board w/Molex

\* Currently repair only.

**WORLD ELEVATOR**

***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*WRLD7601.9009	7601.9009	AC Output Board w/TB
*WRLD7601.9010	7601.9010	AC Output Board w/Molex
*WRLD7601.9011	7601.9011	Relay Board
*WRLD7601.9014	7601.9014	Output Board w/TB
*WRLD7601.9015	7601.9015	Input Board w/TB
*WRLD7601.9018	7601.9018	Tool
*WRLD7602.9002	7602.9002	Mother Board MP21
*WRLD7602.9004	7602.9004	MSU Board MP21
*WRLD7602.9005	7602.9005	CPU Board MP21

\* Currently repair only.

### ***World Elevator PC Boards***

<b><i>Unitec Part No.</i></b>	<b><i>OEM Part No.</i></b>	<b><i>Description</i></b>
*WRLD7602.9006	7602.9006	PI/O Board MP21
*WRLD7602.9007	7602.9007	PROM Board MP21
*WRLD7603.1008	7603.1008	MLS Door Board
*WRLD7603.9002	7603.9002	MAC Speed Control Board
*WRLD7603.9003	7603.9003	MAC Motor Power Board
*WRLD7603.9004	7603.9004	Mother Board
WRLD7603.9008	7603.9008	Door Board

\* Currently repair only.

**WORLD ELEVATOR**







# **UNITEC**

**EXCELLENCE FROM THE GROUND UP**

**(800) 328-7840**  
**[www.unitecparts.com](http://www.unitecparts.com)**