


ELECTRICAL COMPONENTS



No.	Description	Symbol
CONSTANT		
1	Main disconnect switch	MS
2	Starting key switches - upper landing - lower landing	SS 1SS
3a	Broken main drive chain switch	BDC
3b	Main drive shaft brake switch	EBS

No.	Description	Symbol
4	Non-reversal device	FRD
5	Broken step chain switches - L.H. - R.H.	LBC RBC
6	Stop switch, lower landing	SSL
7	Stop buttons - upper landing - lower landing	SB 1SB
8	Step upthrust switches - L.H. lower landing - R.H. lower landing	STSSR STSSL
9	Skirt panel switches - L.H. upper landing - R.H. upper landing - L.H. lower landing - R.H. lower landing	LHSSU RHSSU LHSSL RHSSL
10	Step demarcation lights - upper landing - lower landing	SDLU SDLL
11	Comb plate contacts - L.H. upper landing - R.H. upper landing - L.H. lower landing - R.H. lower landing	LCSU RCSU LCSL RCSL
12	Overspeed governor	OS
13	Brake lifting operation (former OBD)	BLS
14	Brake lining wear	BLWD
15	Inspection box - insp. socket upper ldg. - insp. socket lower ldg.	IB IBU IBL
16	Comb lights	CL
17	Balustrade lighting	BL
18	Step and chain wheel control contact - upper landing - lower landing	RSSU RSSL
19	Stopped handrail device - L.H. upper landing - R.H. upper landing	SHDL SHDR